



2005 Chevrolet C-6 Corvette Cold Air Induction System Part# 1735

INSTALLATION INSTRUCTIONS

Included in this kit: Cold-air casting, coupler hose, 4 hose clamps, 2 air filters.
Tools required: 1/4" ratchet, 8mm, socket.

- Step 1** Place the supplied blue coupler hose over the outlet opening of the BBK cold-air casting and secure it with one of the supplied hose clamps. Place another hose clamp over the open end of the coupler hose.
- Step 2** Place one of the supplied hose clamps over the end of each BBK air filter and secure the filters to the inlets of the cold air casting.
- Step 3** Loosen the hose clamp that attaches the stock air box to the mass air meter.
- Step 4** Remove the stock air box assembly from the vehicle by lifting the air box straight up and pulling the inlet hose away from the mass air meter.
- Step 5** Remove the rubber grommets that locate the stock air box on the radiator cover and swap them over to the BBK cold-air casting.
- Step 6** Guide the assembled BBK cold-air kit into position by placing the outlet hose coupler over the mass air meter, then pushing the rubber grommets down onto the locating pins on the radiator and tightening the remaining hose clamp.

Installation Photos



Remove stock inlet.



Insert rubber grommets.